

RHIMA Pro Wash **SOLID**

Replace empty package in 3 easy steps

Replacing empty Pro Wash SOLID packages with new ones is done quickly and safely. Always remember to use protective equipment in accordance with the instructions.

1



Remove the empty package

The dosing device will alarm once the package is empty. There will be a sound notice and the red light will be lit up. Do not remove the package until it is completely empty.

2



Remove the cap from the new package

The cap can be removed by lightly lifting it from one side.

3



Place the new package into the dosing device

The new package should be placed in a way that the handle of the package is pointed towards you. Please make sure that the RHIMA Pro Wash SOLID is correctly in its place by pushing it all the way down.



Wear protective gloves



Corrosive



RHIMA Nederland B.V.

Energieweg 4-8, 3762 ET Soest
Postbus 17, 3760 AA Soest

T +31 (0)35 609 81 81

F +31 (0)35 609 81 80

E info@rhima.com • www.rhima.com

ORDER OUR

PRO WASH SOLID RANGE



webshop.rhima.com